

VintageView®

WINE STORAGE SYSTEM

Floor to Ceiling Frame (FCF) Installation Instructions

Wine Master Cellars • 2000 S. Dahlia Street, Unit 300, Denver, CO 80222 • phone: 866.650.1500 • fax: 866.650.1501
Please feel free to contact us regarding the assembly of this product.

Each FCF kit contains:

- 2 Frame Pieces
- 40 self-drilling screws
- 2 Plastic Couplers

Before starting, open all Packaging for the FCF and take inventory to make sure you have everything.

Tools Needed:

- Level
- Tape Measure
- Phillips Head Power Screwdriver
- Metal File
- Hack Saw

Recommended Fasteners:

For attachment to drywall ceiling, use spiral inserts or expanding wall anchors for both attachment points. When possible to attach into wood joists, use #10 X 1-1/2" screws.

For attachment directly into wood, use #10 coarse thread 1" screws.

Attaching into concrete we recommend predrilling and using 3/16" X 1" masonry screws or concrete anchors.

FCF Installation Instructions

1. Measure the exact dimension between the floor and ceiling in the exact position you intend to place the frame. Subtract 5 feet (60 inches) from the measured dimension.

Example:

98" floor to ceiling measurement

$98" - 60" = 38"$

2. Using the resulting dimension, measure away from the mounting plate and mark both rails on one of the frame halves.

Note: If the measurement falls on one of the cross members, you will need to cut some off of both halves. Cut 2" off of one half and increase your resulting dimension from step 1 by 2" and mark the 2nd frame half.

3. Using a hack saw, carefully cut both rails squarely at the markings. Clean off any burrs with a metal file. (IMAGE A)

4. Insert the plastic couplers into the ends of one frame piece and slide the two frame sections together. Place the assembled frame on a level surface, so that the frame lays flat with support under the coupled joint.

5. Remove 2 WS series racks from their packaging and remove the plastic end caps from the bottom of one set and from the top of the other set.

6. Determine whether you would like the bottle necks to face left or right. Using the set of WS series racks with the plugs removed from the top, place either the neck or base of the rack on the 5' section of the frame rail. Locate the bottom of the rack to the desired distance above the plate that will be fastened to the floor. Using the provided self-drilling screws, mount the WS series rack to the frame. (IMAGE B)

7. Attach the other side of the rack to the 2nd rail and insert the plastic couplers provided with the WS series racks into the bottom of the 2nd set of racks.

8. Slide the coupler into the 1st rack and attach it to the frame. Repeat for the other half of the rack.

11. Attach the remaining racks or FCF Back to the opposite side of the frame

Note: You may need to offset the racks vertically about 1/8" so that the screws from the opposite side will not interfere with the insertion of screws.

10. Stand the frame in place and shim at the top, if necessary, to achieve a snug fit.

11. Attach the frame to the ceiling first with the appropriate fasteners for your surface*. Using a level, ensure the rack is vertical both side-to-side and front-to-back. Next, attach the frame to the

floor using fasteners suitable for that surface*. (IMAGE C)

12. Load your racks with wine and enjoy the VintageView®!



